
Microinverter APP User Guide

Northern Electric Power Co,. Ltd. Date: 02/2024 Revision: V3.0



Content



1. Account login & registration

- **1.** Log in (P3)
- 2. Registration (P4)
- 3. Reset password (P5)

2. Create a site

- **1. Enter the site information** (P6)
- 2. Add device (P8-25)
 - 1) Gateway device (P8-11)
 - 2) WiFi device (P12-25)
 - * WiFi Configuration (P21-24)

3. User interface

- **1. Site** (P27-28)
- **2. Quick tool** (P29-41)
- **3. Setting** (P42-49)
 - * Parameter setting (P44-49)

Account login & registration -- Log in



- Click 1 to enter the user's email account
- Click 2 to enter the login password
- Click 3 to remember the entered account and password

(After checking this, the account and password will be saved locally if you successfully log in, so you don't need to enter them the next time you log in)

- Click 4 to log in
- Clicking 5 will jump to the password reset page
- Click 6 to jump to the new account registration page

| | ELECTRIC | 3 | | | |
|------------------|----------|------------|-----------------------|------|--|
| Logi Securely | | your acco | unt | | |
| | Email ac | ldress | | 0 | |
| A | Passwor | d | | 2 | |
| 🔿 Rem | ember m | e 3 | | | |
| | | Log i | n | 4 | |
| | | Forgot Pas | sword | 5 | |
| | | | | | |
| | Creat | te An Acco | unt <mark>Sign</mark> | Up 🌀 | |

Account login & registration -- Registration



- Click 1 to enter user name
- Click 2 to enter your email account (login account)
- Click 3 to enter the login password
- Click 4 to enter a phone number (optional)
- Click 5 to select a country and region
- Click 6 to register a new user
- Clicking 7 will jump to the login page

| | ate An Account | .8 |
|---|----------------|-----|
| 2 | Full Name | 0 |
| | Email address | 2 |
| 8 | Password | 8 |
| | Enter number | 4 |
| 3 | Country/Region | 5 |
| | Create Accoun | t 6 |

Account login & registration -- Reset password




- Click 1 to enter the email address where you want to reset your password
- Click 2 to re-enter the email address where you want to reset the password, making sure the two email addresses are consistent.
- Click 3 to send an email to the entered email address, and then modify the password in the email address.
- Click 4 to jump to the login page

| ORTHERN ELECTRIC | | |
|---------------------------------------|--------------|----------|
| Retrieve you ecurely Retrieve your | | unt |
| Email address | 5 | 0 |
| Confirm Email | l address | 2 |
| | | |
| | Send | 8 |
| I Already Have | e an Account | Log in 👍 |

Create a site -- Enter the site information



- Click 1 to select the site picture (optional)
- Click 2 to enter the installer/end user email address (required)
 - If the current creator identity is an installer, you need to enter the end user email address
 - If the current creator identity is an end user, you need to enter the installer's email address
- Click 3 to enter the site name (required)
- Click 4 to select the country and region (required)
- Click 5 to enter the city (required)
- Click 6 to enter the street (optional)
- Click 7 to select the time zone (required)
- Click 8 to select the currency (required)
- Click 9 to select the temperature unit (optional)
- Click 10 to select commission (default NO)
- Click 11 to enter the sharing email address (optional)
- The entered email address can also see this site, only view permission
- Click 12 to confirm creating the site





Gateway device (details on P8-11)


- Click 1/2 to switch the device type that needs to be added. The selected style is 1
- Click 3/4 to choose how to enter the serial number
- Click 3 to manually enter the serial number
- Click 4 to scan the barcode to import the serial number
- Click 5 to delete the current serial number
- Click 6 to modify the current serial number
- Area 7 displays the serial number entered via 3/4
- Click 8 to submit data

| Add Site demo Type 1 Gateway 2 WIFI Ways to add a device 3 Manually 4Barcode Serial Number 214988888888999 Gateway 5 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 | 12:55 | | 🤌 🖾 Sal Sal 📼 |
|--|---------------|----------|---------------|
| Type 1 Gateway 2 WIFI Ways to add a device 3 Manually 4Barcode Serial Number 214988888888999 5 6 8 78 | | Add Site | |
| 1 Gateway 2 WIFI Ways to add a device 3 Manually 4Barcode Serial Number 21498888888999 5 60 78 | demo | | |
| Ways to add a device 3 Manually 4Barcode Serial Number 214988888888999 5 6 6 78 | Туре | | |
| 3 Manually 4Barcode Serial Number | 1 Gateway | 2 WIFI | |
| Serial Number | Ways to add a | device | |
| 7 21498888888999 5 🔐 📨 | 3 Manually | 4Barcode | |
| | Serial Numb | er | |
| | | | 5 |
| | | | |
| | | | |
| | | | |
| | | | |
| 8 Submuit | | | |



Gateway device (instructions for P7)


Click 3 to manually enter the serial number
 A pop-up window will appear, enter the 14-digit SN





Gateway device (instructions for P7)


 Click 4 to scan the barcode to import the SN Different mobile phones have different styles
 Just align the middle scanning area with
 the corresponding serial number barcode





Gateway device (instructions for P7)

Click 5 to delete the current serial number
 Clicking yes will delete the current SN





Gateway device (instructions for P7)

- Area 7 displays the serial number entered via 3/4
 Note: There will be 3 states
 - OK, means the SN is correct
 - Exist, means the SN has been bound by other sites
 - Err, means the serial number is wrong

| 2:55 | 🖉 🖼 Sal Sal 📼 | 12:55 | 🖉 🖾 Sati Sati 📼 - |
|---------------------------|--|--------------------------|-------------------|
| Ade | d Site | 4 | dd Site |
| demo | | demo | |
| Туре | | Туре | |
| Gateway 2 WIFI | | 1 Gateway 2 W | FI |
| Ways to add a device | | Ways to add a device | |
| 3 Manually 4Barco | de | 3 Manually 4Bar | code |
| Serial Number | | Serial Number | |
| 21498888888899 Gateway | 9 ⁹ 5 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | 7 21498888888 Gateway | 999 5 🕯 🧭 6 |
| | | | |
| 8 s | lamit | 8 | Submit |




WiFi device (details on P13-25)

- Click 1/2 to switch the device type that needs to be added. Select 2
- Click 3/4/5 to choose how to enter the serial number
- Click 3 to manually enter the serial number
- Click 4 to scan the barcode to import the serial number
- Click 5 to automatically scan nearby devices. You need to ensure that the WiFi switch is

turned on on the current phone (IOS does not have this function)


- Click the small icon to the left of 6 to show how to put the device into WiFi configuration.
- Area 7 displays the serial number entered via 3/4
- Click 8 to delete the current serial number
- Click 9 to modify the current serial number. Note that the scanned SN cannot be modified
- Click 10 to configure the network for SN
- Click 11 to submit data





WiFi device (instructions for P12)


Click 3 to manually enter the serial number
 A pop-up window will appear, enter the 8-digit SN.
 The picture on the right shows the wrong SN.





WiFi device (instructions for P12)

 Click 4 to scan the barcode to import the SN Different mobile phones have different styles Just align the middle scanning area with the corresponding serial number barcode







必知詞意题 12:57 必知知念回 12:56 Add Site Add Site demo demo Туре Gateway Gateway × Ways to add a device Place mobile close to the Wifi device 🚯 Manually 👍 Barcode 🚯 Auto Search 🗌 🌀 Search Results (0) Serial Number 3BCF00A0 🗎 I. BDH-800 🔆 Configure WiFi 3BC00000 ii<l BDH-800 10 Configure WiFi Search Again Confirm 0

WiFi device (instructions for P12)


Click 5 to automatically scan for nearby devices
 You need to make sure that the WiFi switch is turned
 on on your current phone

The picture shows the scanning in progress page



WiFi device (continued from previous page)


- Automatically scan for nearby devices
 - The picture shows the scan results page
- Click 1 to select the SN, and all are selected by default.
- Click 2 to add the selected SN to the serial number list, and close the pop-up window
- Click 3 to search again
- Click 4 to close the page





WiFi device (instructions for P12)

 Click the small icon to the left of 6 to show how to put the device into the WiFi configuration state
 The prompt as shown in the picture is just a simple prompt without any function.






WiFi device (instructions for P12)

• Area 7 displays the serial number entered via 3/4

Note: There will be 3 states


- OK, means the SN is correct
- Exist, means the SN has been bound by other sites
- Err, means the serial number is wrong





WiFi device (instructions for P12)

Click 8 to delete the current serial number
 Clicking yes will delete the current SN





WiFi device (instructions for P12) Click 11 to submit data (can only be submitted if all 7 areas are OK) Exist exists in area 7 in the left picture, so it cannot be submitted.


- The status of the 7 areas on the right are all OK, the **Submit** button appears, and you can submit

| 12:57 | 必知知 余 🔍 | 2 | | |
|-------------------------------------|-----------------|------------------------|-------------------------------|-----------------|
| Add Site | | 12:58 | Add Sit | 2 🖾 Cal Cal 🕫 🖾 |
| demo | | demo | | - |
| Туре | | Туре | | |
| 1 Gateway 2 WIFI | | Gateway | WIFI | |
| Ways to add a device | | Ways to add a | device | |
| 3 Manually 👍 Barcode 👩 | Auto Search 💿 🌀 | Manually | Barcode | Auto Search |
| Serial Number | | Serial Numbe | r | |
| 3BCF00A0 BDH-800 🔆 Configure Wif | <u>n</u> 🗎 🖸 | 389994 BDM-W | 194 IFI 餐 <u>Configure</u> | WIFI 🗑 🔀 |
| BDH-800 0 Configure Wife | ± | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | _ | |
| | 0 | Connection T | lest | Submit |
| | | | | |



WiFi device (instructions for P12)

- Click 10 to configure the network for SN
 The picture on the right shows the home WIFI account and password input page.
 - Click the menu to the right of 1 to select WIFI,
 Click the input box to the left of 1 to enter the
 WIFI name
 - Click 2 to enter the WIFI password
- Click 3 to conduct a connectivity test and start to WiFi configure
- Click 4 to cancel network provisioning





WiFi Configuration (continued from previous page no.3)


- Conduct a connectivity test and start WiFi configuration by entering the account and password
 - The picture shows the test passing page

| 12:57 | | 🖉 📟 धना धना 🗇 📼 |
|-----------------|---------|-----------------|
| | Add Sit | ė |
| demo | | |
| Туре | | |
| Gateway | WIFI | |
| Ways to add a d | levice | |
| Manually | Barcode | Auto Search |
| Serial Number | | |
| | | |
| | | |



WiFi Configuration

- Start configuring, the icon in the red box in the picture will rotate
- After the configuration is completed, you will be prompted whether to perform a connectivity test.
- Click OK to check the device's networking status
- Clicking Cancel will not perform the test






WiFi Configuration

• The device's networking status is normal

The picture shows the results displayed by the end user

The device IP will be displayed in the red box in the installer's 1 area.


Click the 2 area button to re-test





WiFi device (instructions for P12)

- Creation completed
 - The page is as shown in the picture
- Click 1 to jump to the homepage
- Click 2 to jump to the device details page






Tabbar

• As shown in the figure, they are the site page, quick tools page, and settings page in sequence.

The selected item will be displayed in green.





Site

- The site page displays the user's site list instead of the device list
 - The picture on the left shows the data status of the site list.
 - In Android system, if you long press each ITEM,
 Edit & Delete will appear.
 - In IOS system, if you swipe left on each ITEM, Edit & Delete will appear.
 - Click Edit to edit the site information.
- Please refer to creating a site for operation
- Click Delete to delete the site

| 12:59 | <u> 2</u> |) 2011 ²⁰ 11 💎 💿 | 3:39 | 🧳 📾 Sall Sal |
|---|--------------|---------------------------------------|---|----------------------------------|
| Search | SN/Plat name | ۹ | Search SN/Plat name | |
| demo 2899 Updated in SID User Instatler address Reg Date | | Today 0 Wh Total 0 Wh Power 0 W | demo S8999204 Updated in - SID US_20240220_V User demo123456@qqc Installer 1641455288@qqc address dihh,Alabama,United Sta Reg Date 2024-02-20.04 | iom Today Total ites Power |
| | No more data | | No more dat | 2 |
| | | | | |
| | | | | |
| | | | Edit | |
| | | | Delete | |
| â | | | | |



Site

• The site page displays the user's site list

The picture shows the site list with no data status

- Click ADD SITE to jump to the page for creating a site

| 12:51 | v⊈ 100 ⁵⁶ .ull ⁵⁶ .ull ®2) [,] |
|---------------------|---|
| Search SN/Plat name | Q |
| | |
| ADD SITE | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |



Quick tool

- Click the middle button of the tabbar to display the quick tools
- Click 1 to jump to the page for creating a site
- Click 2 to jump to the add device page
- Click 3 to jump to the quick WiFi configuration page
- Click 4 to jump to AP mode
- Click 5 to jump to AT mode
- Click 6 to close the current page






Add Device Select a site > Site Type 0 WIFI Ways to add a device Add devices 2 Select a Site First Add New Devices to an Existed Site Confirm (2) Cancel Configure Network E --- 👘 AP Mode 4 6 X 6

Quick tool (instructions for P29)

- Click 2 to jump to the add device page The picture on the right shows the add device page
- 1 prompts to select a site
- Click 2 to jump to the site selection page




Add device (continued from previous page) Click 1 to search for sites Click 2 to select the site. After selection, the gray icon on the left will turn green Click 3 to confirm your selection





Add device (continued from previous page)


- 1 will display the name of the selected site
 Click again can select the site again
- 2 will display the added device types
- If any devices have been added to the site before, the type here must be consistent with the previous devices, so the other option will be closed
- Devices that have been bound to the previous power station are displayed in 3 places
- For the subsequent process, please refer to the second step of 'creat a site'





Quick tool (instructions for P29)


 Click 3 to jump to the quick WiFi configuration page The picture on the right shows the prompt page that introduces how to put the device into WiFi configuration mode





Quick WiFi configuration (continued from previous page)


- Click 1 to enter the WIFI account
- Click 2 to enter the WIFI password
- Click 3 to select nearby WiFi
- Click 4 to proceed to the next step





Quick WiFi configuration (continued from previous page)


- Select the devices that require network distribution
- Clicking 1 will refresh the automatic search for nearby devices
- Click 2 to add devices manually






Quick WiFi configuration (continued from previous page), Device

- Add devices manually
- Click 1 to enter the system page and select the device to be connected
- Select the device WiFi you want to connect to and return to the APP














AP mode (instructions for P29)

- Click 4 to jump to AP mode
 You need to manually select the device you want to connect to on the system WiFi page
- Click 1 to open system WiFi settings
- Select the device WiFi you want to connect to
- Return to APP








AP Mode (continued from previous page)


- Click 1 to enter the parameter setting page
- Different SNs have different setting parameters. The picture on the right is for reference only.
- Parameter settings will be explained in detail in the next chapter





AT Mode (instructions for P29)

- Click 5 to jump to AT mode
 Automatically search for nearby devices
- Click the corresponding SN to set parameters
- Different SNs have different setting parameters. The picture on the right is for reference only.





Setting

- Click 1 to jump to the inverter setting page. please refer to P39-41 for operation
- Click 2 to jump to the add device page, please refer to P30-32 for operation
- Click 3 to jump to personal information settings

| 1:02 | demo amo123456@qq.cd | 愛 Sal Sal 電 変 (回) |
|---------------------|-------------------------|-------------------|
| 1 herie Settinge | Attlences | Account Set lings |
| | | |
| â | ē | ĉ |



Setting

- Personal information settings
- Click 1 Sign Out will log out and jump to the login page
- Click 2 will log out the current account and no longer retain any data, please

pay attention to the operation


- Click 3/4/5/6 to jump to the personal information setting page
- Click 7 to switch languages






- BDM Output Power Adjust
- The picture below shows the function button
- The picture on the right shows the settings page (same for Android & IOS)

| BDM-800 SN:33CFFFFA |
|------------------------------|
| Settings |
| Current device power \rm 🛛 W |
| 600 |
| |
| Save |
| |
| |





- View / Set Parameter
- The picture below shows the function button
- The picture on the right shows the settings page (same for Android & IOS)



| Voltage Range | | | | |
|-------------------|--------------------------------|--|--|--|
| 221V - 270V | / | | | |
| | Over Voltage Protection | | | |
| 170V - 219V | / | | | |
| 0.05-0.25 | Under Voltage Protection | | | |
| 0.00 0.20 | Tip Time for Protection | | | |
| Nominal Frequency | | | | |
| 60Hz | | | | |
| Frequency Range | | | | |
| 60.1-64.5 | / | | | |
| | Over Frequency Protection | | | |
| 55.5-59.9 | / | | | |
| | Under Frequency Protection | | | |
| 0.05-0.25 | / | | | |
| | Tip Time for Protection | | | |
| Reconnection | | | | |
| 60 - 300 | / | | | |
| | Connection Reconnection Period | | | |
| Check | Set | | | |
| Done | | | | |



- Power Control Limit
- The picture below shows the function button
- The picture on the right shows the settings page (same for Android & IOS)



| BDZN-WIFI SN:F0C0004C | |
|----------------------------|-----|
| Settings | |
| Power Control Limit: 640 W | |
| | |
| 0 | 800 |
| | |
| | |
| | _ |
| Save | |
| | |
| | |




- Upgrade
- The picture below shows the function button
- The picture on the right shows the Android settings
- IOS does not have this function yet

| <- | Upgrade | grade | | |
|-----------------|---------|----------|--|--|
| SN | | F0C0004C | | |
| Current Version | | 105 > | | |
| | Upgrade | | | |




- Adjust RTC time
- The picture below shows the function button
- The picture on the right shows the settings page (same for Android & IOS)



| | 3BC04 RTC time | 45D | 0 | | | | |
|--------------------------------|--------------------------|-----|----|-----|--|--|--|
| □ → ⓒ Sync by Cell Phone | | | | | | | |
| Mar | nual Se | t | | | | | |
| | 9 | | 28 | AM | | | |
| | 10 | : | 29 | PM | | | |
| | 11 | | 30 | | | | |
| | Check | | | Set | | | |



- Inverter Scheduling
- The picture below shows the function button
- The picture on the right shows the settings page (same for Android & IOS)



Charge/Discharge/ **Output Schedule** Schedule inverter output according to the following priority Required Inverter Output **Charging Battery** Maximum Inverter Output Configurate by hour 0w 600w **Required Inverter Output** Maximum Inverter Output 0 10 11 600w 0w 12 13 **Required Inverter Output** Maximum Inverter Output 14 15 16 17 18 19 600w 0w 20 21 **Required Inverter Output** Maximum Inverter Output 22 23 Check

 \leftarrow